# kansari-project1

February 24, 2024

## 0.0.1 Project 1 (By: Kashif Ansari)

```
[1]: #Connecting google drive
from google.colab import drive
drive.mount('/content/drive/', force_remount=True)
```

Mounted at /content/drive/

```
[2]: # Change the working directory
path_to_folder = "ENPM673/tutorials"
%cd /content/drive/My\ Drive/{path_to_folder}
```

/content/drive/My Drive/ENPM673/tutorials

```
[3]: #Importing the required libraries
import cv2
import os
from matplotlib import pyplot as plt
from google.colab import drive
from google.colab.patches import cv2_imshow
from IPython.display import clear_output
import numpy as np
from IPython.display import clear_output
```

### 0.0.2 Reading Images

The code below reads a video file named 'object\_tracking.mp4' using OpenCV (cv2). It then extracts properties such as frame width, frame height, and frames per second (fps). After that, it initializes a VideoWriter object to save the processed video with the same properties as the input video but with the name 'output\_video.mp4'.

Next, it iterates through each frame of the input video, finding the coordinates of dark pixels (pixels with values less than 10) in each frame. It then calculates the centroid (average position) of these dark pixels and draws a green circle at that centroid position on each frame. The centroid positions are also stored in lists.

Finally, it converts each frame to grayscale, displays it, and writes it to the output video file. Once all frames have been processed, it releases the VideoCapture and VideoWriter objects, indicating the end of the process.

#### 0.0.3 Reading Video

```
[4]: # Read a video
     video_capture = cv2.VideoCapture('assets/object_tracking.mp4')
     # Get video properties
     frame_width = int(video_capture.get(cv2.CAP_PROP_FRAME_WIDTH))
     frame_height = int(video_capture.get(cv2.CAP_PROP_FRAME_HEIGHT))
     fps = int(video_capture.get(cv2.CAP_PROP_FPS))
     # Define the codec and create VideoWriter object
     fourcc = cv2.VideoWriter_fourcc(*'XVID')
     out = cv2. VideoWriter('output_video.mp4', fourcc, 30.0, (frame_width,__
      →frame_height), 0)
     # Read and save each frame
     dark_pixels_x = []
     dark_pixels_y = []
     centroid_x_list = np.array([])
     centroid_y_list = np.array([])
     #Loop to return the frame captured
     while True:
         ret, frame = video_capture.read()
         if not ret:
             break
         # Find coordinates of dark pixels in the frame
         dark pixel coordinates = np.where(frame < 10)</pre>
         dark_pixel_x = dark_pixel_coordinates[1] # x coordinates (column indices)
         dark_pixel_y = dark_pixel_coordinates[0] # y coordinates (row indices)
         #Capturing boundry pixels
         if dark_pixel_x.size > 0 and dark_pixel_y.size > 0:
           max_x = np.max(dark_pixel_x)
          min_x = np.min(dark_pixel_x)
          max_y = np.max(dark_pixel_y)
           min_y = np.min(dark_pixel_y)
           #Calculating centroid
           centroid_x_co = int((min_x)+((max_x-min_x)//2))
           centroid_y_co = int((min_y)+((max_y-min_y)//2))
           # print(centroid_x_co)
           centroid_x_list = np.append(centroid_x_list, centroid_x_co)
```

```
centroid_y_list = np.append(centroid_y_list, centroid_y_co)
      # Circle parameters
      center_coordinates = (centroid_x_co, centroid_y_co) # Center of circle
     radius = 10 # Radius of the circle
      color = (0, 255, 0) # Green color in BGR format
     thickness = -1 # Thickness of the circle outline (negative value to fill_
 → the circle)
     cv2.circle(frame, center_coordinates, radius, color, thickness)
   frame = cv2.cvtColor(frame, cv2.COLOR_RGB2BGR)
   frame1 = cv2.cvtColor(frame, cv2.COLOR_RGB2GRAY)
   cv2_imshow(frame1)
   # Clear the output cell to update the frame
   clear_output(wait=True)
   out.write(frame1)
# Release VideoCapture and VideoWriter objects
video_capture.release()
out.release()
```



#### 0.0.4 Curve fitting process


This code calculates the coefficients (A, B, C) for a quadratic function that best fits the data points represented by the centroid positions stored in centroid\_x\_list and centroid\_y\_list.

[ 6.46970531e-04 -1.24536917e+00 9.86878990e+02]

```
[6]: #Getting corresponding Y cordinate (exp) from obtained value of A,B,C
exp = (B[0] * centroid_x2_list) + (B[1] * centroid_x_list) + B[2]
centroid_y_list.shape
```

[6]: (528,)

```
[7]: #Plotting the parabolic grpah
plt.scatter(centroid_x_list, centroid_y_list, color = "yellow")
plt.plot(centroid_x_list , exp)
#Inverting the parabola to match the graph
plt.gca().invert_yaxis()
plt.grid(True)
```



## 0.0.5 Capturing frame and plotting graph

The code snippet below opens a video file named 'output\_video.mp4' using OpenCV (cv2). It then checks if the video file was opened successfully. If not, it prints an error message and exits the program.

The code sets a desired time in milliseconds (desired\_time\_ms) to capture a frame from the video. For example, if desired\_time\_ms is set to 15000, it captures a frame at 15 seconds into the video.

Then, it sets the frame position in the video using video\_capture.set(cv2.CAP\_PROP\_POS\_MSEC, desired\_time\_ms).


Next, it reads the frame at the desired time using video\_capture.read(). If the frame is not read successfully, it prints an error message and exits the program.

After that, it displays the frame using Matplotlib (plt.imshow(frame)), and plots a graph using the data stored in centroid\_x\_list and exp (assuming exp is defined elsewhere in the code). It then waits for any key to be pressed (cv2.waitKey(0)) and closes all OpenCV windows (cv2.destroyAllWindows()).

```
[8]: # Open the video file
video_capture = cv2.VideoCapture('output_video.mp4') # Replace 'video.mp4'

→with your video file
```

```
# Check if the video opened successfully
if not video_capture.isOpened():
   print("Error: Could not open video file")
   exit()
# Set the desired time in milliseconds
desired_time_ms = 15000 # For example, to capture a frame at 5 seconds into_
⇔the video
# Set the frame position in the video
video_capture.set(cv2.CAP_PROP_POS_MSEC, desired_time_ms)
# Read the frame at the desired time
ret, frame = video_capture.read()
# Check if the frame was read successfully
if not ret:
   print("Error: Could not read frame")
   exit()
# Display the frame (optional)
# cv2_imshow(frame)
plt.imshow(frame)
plt.plot(centroid_x_list , exp)
plt.gca().invert_yaxis
plt.show()
# Wait for any key to be pressed
cv2.waitKey(0)
cv2.destroyAllWindows()
# Release the video capture object
video_capture.release()
```



## 0.0.6 Calculation for the unknown Y co-ordinate at gaiven X co-ordinate

```
[9]: #Calculating the y cordinate for the given x axis
given_x = 1000
a, b, c = tuple(B)
required_y = a*given_x**2 +b*given_x + c
print ("corresponding y cordinate is:", required_y)
```

corresponding y cordinate is: 388.4803497221982